

PRODUCT CODE 1023, 1025

WoodTech PU Palette Exterior

Asian Paints WoodTech PU Palette Exterior is an acrylic based opaque coating, which offers excellent weather resistance, light-fastness and UV protection.

PRODUCT BENEFITS

Over 2500+ Shades

WoodTech PU Palette rolls out a sweeping range of 2500+ Stylish shades adding versatility and elegance to all wood surface. It is applicable on wood, metal, and glass surface.

Superior Resistance

WoodTech PU Palette Exterior has good scratch, stain and heat resistance.

Exterior Durability

WoodTech PU Palette Exterior has UV Guards, which make the product excellent for exteriors, also has high film flexibility, which makes the product resist cracking even on curved surfaces.



SOLVENT BASED

PRODUCT FEATURES

DURABILITY



COVERAGE



**Actual coverage may vary from the quoted coverage due to factors such as method and condition of application and surface roughness and porosity.


COLOURS AVAILABLE



FINISH



AVAILABLE PACKS



HOW TO APPLY

PRE PAINTING STEPS



PAINT APPLICATION PROCESS

APPLICATION	CODE	MIXING RATIO BASE:HARDENER	THINNER	DILUTION %	APPLICATION VISCOSITY	RECOATING PERIOD
STEP 1 WOODTECH PU PALETTE EXTERIOR WHITE OR GREY FIRST COAT/SPRAY	1025	90:10	PU THINNER (1532/5442)	SPRAY : UPTO 50%	SPRAY 17 - 21 SECS	4 - 5 HOURS
STEP 2 SANDING	SAND THE SURFACE WITH SAND PAPER 320 OR 400 AND WIPE CLEAN					
STEP 3 WOODTECH PU PALETTE EXTERIOR WHITE OR GREY SECOND COAT/SPRAY	1025	90:10	PU THINNER (1532/5442)	SPRAY : UPTO 50%	SPRAY 17 - 21 SECS	4 - 5 HOURS
STEP 4 SANDING	SAND THE SURFACE WITH SAND PAPER 320 OR 400 AND WIPE CLEAN (APPLY THIRD COAT IF REQUIRED AFTER SANDING WITH SAND PAPER NO. 320 / 400 AND WIPE CLEAN)					
STEP 5 WOODTECH PU PALETTE EXTERIOR GLOSSY SHADE FIRST COAT/SPRAY	1023	80:20	PU THINNER (1532/5442)	SPRAY 25 - 30	SPRAY 17 - 21 SECS	12 -14 HOURS
STEP 6 SANDING	SAND THE SURFACE WITH SAND PAPER 320 OR 400 AND WIPE CLEAN					
STEP 7 WOODTECH PU PALETTE EXTERIOR GLOSSY SHADE SECOND COAT/SPRAY	1023	80:20	PU THINNER (1532/5442)	SPRAY 25 - 30	SPRAY 17 - 21 SECS	12 - 14 HOURS
(APPLY THIRD COAT IF REQUIRED AFTER SANDING WITH SAND PAPER NO. 320 / 400 AND WIPE CLEAN)						

NOTE: 1. WoodTech PU Palette Exterior should be thoroughly stirred and mixed with the hardener and thinner in the specified mixing ratio. 2. Maturation time is 30 minutes. 3. If the wood is previously coated, remove the coating by scraping before application of WoodTech PU Palette Exterior as per the above recommended procedure. 4. WoodTech PU Palette Exterior must not be polluted with oil, varnish or the like and

must not be sanded with steel wool between coats. 5. If the coating gets physically damaged (cuts and dents) due to impact of sharp objects or any other means, after application or in normal usage, then the damaged surface has to be repaired by application of fresh coats of WoodTech PU Palette Exterior on the specific area. 6. Recoat period is quoted for 30°C and 75% relative humidity, these may vary under different conditions. 7. Spraying

air pressure 2.2 to 2.8 Kgs/sq.cm. 8. Viscosity as measured through a Ford cup B4 at 30°C. 9. Base and hardener of 2 pack system must be consumed within one week of opening the fresh containers. The containers should be tightly closed after use to avoid any moisture contamination with the liquid material.

HOW TO CHOOSE COLOURS

Browse through Asian Paints colour tools to help you find the right colour combination

WOODTECH PU PALETTE
SHADE CARD



PU PALETTE
SHADE CARD



WOODTECH
PIGMENTED FOLDER



WOOD
SPECTRA



Note: The final shade will vary on the basis of the color of the veneer, no of coats applied and dilution of the wood stains.

ADDITIONAL INFORMATION

POST PAINTING CARE

For removing stains on tiles and metal surfaces, apply A1/A1 Gold Thinner/NC Thinner on the surface and wipe clean. If stains are difficult to remove, scrapping can be done after applying A1/A1 Gold Thinner/NC Thinner on the stained area.

Precautions need to be taken while spraying / brushing, like masking of adjoining areas with suitable material, as the stains may be difficult to remove if present on wood or coated wooden and wall surfaces.

TECHNICAL DETAILS

- a. Drying time:** Touch to Dry 25 minutes. Tack Free time 3 hours max
- b. Gloss levels:** 90% minimum (Glossy) on coated wooden pannel at 60° Gloss Head
- c. Flash point (IS 101/1987, Part 1, Sec 6):** Above 15°C (59°F)
- d. Stability of thinned paint:** To be used within 3 hours
- e. Shelf Life:** 2 year from date of manufacture in original tightly closed container away from direct sunlight and extensive heat

PRECAUTIONS

- For optimum performance, Asian Paints WoodTech PU Palette Exterior must be applied at a temperature between 20°C and 40°C and humidity not above 75%.
- Do not over-thin and mix according to recommended ratios.
- Stir well and strain before use.
- For best performance, choose appropriate % of the thinner as per the climatic conditions. Choose slow drying thinner for application at higher temperature.

SAFETY FEATURES

- Kindly refer to the MSDS for Asian Paints WoodTech PU Palette Exterior, which gives detailed information on safety measures while handling the paint.
- Store the product at ambient conditions in well ventilated locations and away from source of ignition and fire.
- Use protective equipment like rubber/polyurathane gloves, safety goggles/glasses, face mask while handling the paint.
- Avoid eye and skin contact. In both cases wash with soap and plenty of water. Get medical attention if irritation develops or persists.
- Do not inhale or ingest. In case of inhalation move to fresh air and seek medical attention if symptoms persist in both cases.
- No added Lead, Mercury or Chromium compounds.
- Left-Over Paint Disposal: Left-over paint/drums should not be disposed in soil/drains.
- Consumers should consult a local recycling agency for proper disposal of paint/drums.