



Royale Glitter Royale Glitter Sheen levels are shown for indication purpose only.

MATT FINISH Royale Matt

HI SHEEN FINISH

NEO GOLD FINISH

Royale Shyne

SOFT SHEEN FINISH

NEO SILVER FINISH

Royale Aspira



Sand the surface with Sand Paper No. 180 to remove loose

Apply 1 coat of Asian Paints TruCare interior wall primer and allow drying for 4 – 6 hours.

Apply another coat of Asian Paints TruCare interior primer and allow drying for 4 – 6 hours. Sand the surface with sand paper No. 320 or 400 and wipe clean.

Smoothen the surface with coats of Asian Paints Trucare Acrylic Wall Putty. Allow drying for 4 – 6 hours. Sand the surface with Sand Paper No. 180 and wipe clean.

Thin 1 litre of Royale Luxury Emulsion with 400 – 500 ml

particles or dirt and wipe clean.

of water.

Free sample. Not for retail sale.

Apply 2 – 3 coats of Royale Luxury Emulsion with a 4 – 6 hour gap between each coat using a felt roller. For best results, use Asian Paints Royale Roller for application. For best results, use:

ASIAN PAINTS SERVICES: 🚵 consultancy@home For Colour Consultancy at Home SMS 'CCH' to 56161. 🏚 home solutions For Professional Painting Service SMS 'PAINT' to 56161.

ezycolour log on to www.asianpaints.com, or call us at: 1800-209-5678

Asian Paints Limited, 6A, Shantinagar, Santacruz (East), Mumbai - 400055.

For more information on painting and colour selection,

Asian Paints Range TruCare interior of Painting Tools wall primer