

PRODUCT CODE: 0036

# Royale Glitter

Asian Paints Royale glitter Emulsion is an exquisite emulsion paint that provides luxurious metallic finish and a silky glowing appearance to your walls.

# **PRODUCT BENEFITS**

#### Green Assure

The promise of Green Assure from Asian Paints, implies that this product conforms to strict international environmental and safety standards. Low VOC standards and the absence of any harmful chemical results in very low odour.

#### Anti- Bacterial and Anti- Fungal Shield

Royale Glitter is designed to prevent fungal growth on walls. It also offers a unique anti- bacterial shield.





\* All Asian Paints products contain no added Lead, Mercury, Arsenic or Chromium

# **PRODUCT FEATURES**

# WASHABILITY COLOURS AVAILABLE COVERAGE



43

\*Currently available 43 shades as per the Asian Paints Glitter cards.



# **AVAILABLE PACKS**



# **FINISH**









\*\*Actual coverage may vary from the quoted coverage due to factors such as method and condition of application and surface roughness and porosity.

# **HOW TO APPLY**

#### PRE PAINTING STEPS



PLASTER New masonry surfaces must be allowed to cure completely. It is recommended to allow 28 days as the curing time for new masonry surfaces.



CLEANING Surface should be free from any loose paint, dust or grease. Growths of fungus, algae or moss should be removed by wire brushing and water. When the underlying surface exhibits chalkiness, in spite of thorough surface cleaning, use TruCare EXTERIOR WALL PRIMER SEALER



#### FILLING FOR HOLES & DENTS

In case of dents and holes use Asian Paints TruCare Acrylic Wall Putty or white cement and fine sand in the ratio 1:3

## **PAINT APPLICATION PROCESS**

7 411 7 41 1 21 67 11 10 1		<u> </u>			
APPLICATION	CODE	THINNER	DILUTION %	APPLICATIO N VISCOSITY 1	RECOATING PERIOD
TEP 1 Anding	SAND THE SURFACE WITH SAND PAPER 180 AND WIPE CLEAN				
ITEP 2  Trucare Wall  Trucare Wall  Trucare Wall  Primer Saler(WB)  BRUSH / ROLLER / SPRAY	0061 0060	↑ T 101*	BRUSH / ROLLER 10-15 SPRAY 15 - 20 80% - 100 %	BRUSH / ROLLER 35-50 SPRAY 20 - 25 BRUSH / ROLLER 30 - 40 SPRAY 20 - 25	8 - 10 HR 4 - 6 HR
TEP 3 sian Paints TruCare CRYLIC WALL PUTTY UTTY KNIFE	0064	<b>WATER</b>	BASED ON REQUIREMENT	N/A	6-8 HRS
TEP 4 Anding	SAND THE SURFACE WITH SAND PAPER 180 AND WIPE CLEAN				
TEP 5 TruCare WALL RIMER SEALER(WB) RRUSH / ROLLER / SPRAY	0060	<b>WATER</b>	80% - 100 %	BRUSH / ROLLER 30 - 40 SPRAY 20 - 25	4 - 6 HRS
TEP 6 Anding	SAND THE SURFACE WITH SAND PAPER 180 AND WIPE CLEAN				
STEP 7 TWO COATS APCOLITE PREMIUM EMULSION RUSH / ROLLER / SPRAY	0021	<b>WATER</b>	BRUSH / ROLLER 40 -50 SPRAY 65	BRUSH/ROLLER 50 - 70 SPRAY 22 - 25	4 - 6 HR
TEP 8 WO COATS ROYALE GLITTER RUSH / ROLLER / SPRAY	0036	WATER	BRUSH / ROLLER 40 - 45 SPRAY 65	BRUSH / ROLLER 70-80 SPRAY 22-25	6 - 8 HR



# **HOW TO CHOOSE COLOURS**

Browse through Asian Paints colour tools to help you find the right colour combination

COLOUR SPECTRA FAN DECK\*

INTERIOR COLOUR
COMBINATIONS GUIDE













<sup>\*</sup>These shades are for reference only. Please refer to the Colour Spectra or Colour Palette for correct shade reference

# **ADDITIONAL INFORMATION**

#### **VOC CONTENT**



#### **PRECAUTIONS**

- > Do not apply when ambient temperature is less than 10°C or if the temperature might drop to this level within 4 hrs of application.
- > Do not over-thin or over-extend the brush.
- > Tint using Asian Paints machine colourants only
- > Stir well and strain before use.
- > Tinted paints need thorough shaking immediately after tinter addition as well as before use.

#### **POST PAINTING CARE**

- The Golden rule for removing any wall stains is that one should remove it immediately.
- Remove all dirt using a clean cloth or duster. Always remove dirt from top to bottom, this helps in avoiding loose dirt to smudge the walls.
- For regular household stains like pencil, tea, coffee, crayons etc, use 5% soap/ detergent solution. Use a sponge to remove the stains.
- In case of tough stains like turmeric, sketch pen, use a mild detergent solution (e.g Pril, Vim Liquid etc) for cleaning the stains.

## **TECHNICAL DETAILS**

a. Drying time: Surface dry time 30 min
b. Sheen levels: 8 - 14 at 60 deg GH
c. Flash point IS101/1987 Part 1, Sec 6: NA
d. Stability of thinned paint: To be used

within 6-8 hours

#### **SAFETY FEATURES**

- Kindly refer to the MSDS for Asian Paints Royale Glitte which gives detailed information on safety measures while handling the paint, which is available on request.
- > Store the container with the lid tightly closed in an upright position, in a cool, dry place
- > Keep out of reach of children and away from eatables.
- May be harmful if swallowed. In case of ingestion seek immediate medical attention.
- Wear eye protection during application. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- In case of skin contact immediately wash skin with soap and plenty of water. Get medical attention if irritation develops or persists.
- Do not breathe vapour or spray.lt is recommended to wear suitable nose pad during sanding and surface preparation to avoid dust inhalation.
- Do not pour leftover paint down the drain or in water courses.
- > In the event of spills, contain spillage using sand or earth.
- > No added Lead, Mercury or Chromium compounds.



ersion No. VN01/03/