

PRODUCT CODE 1028

Professional FineTex

Asian Paints Professional FineTex is a modified acrylic, water-based exterior product specially designed as an intermediate coating. It facilitates excellent adhesion of subsqequent coats. It offers a unique textured pattern which has a distinctive appeal.

PRODUCT BENEFITS

Hides Cracks

It hides surface undulations and fine cracks.

Good Adhesion

Resists efflorescence and lime blooming with good adhesion on all cement plasters. It promotes adhesion of subsequent coats.

It serves as an undercoat which will provide protection and decor for a variety of exterior and interior surfaces.

Tough Textured

The tough textured finish lasts for a long time and ensures low maintenance.





PRODUCT FEATURES

FINISH









Tough Texture: Lasts long and ensures low maintenance

COLOURS AVAILABLE



AVAILABLE PACKS



Shelf life: 3 years from date of manufacture in original tightly closed containers away from direct sunlight and excessive

COVERAGE

On normal masonry surface by rolling to obtain an even coating of $\sim 0.5~\text{mm}$ - 1~mm



1 COAT 10 - 12 sq.ft/kg**

HOW TO APPLY

PRE PAINTING STEPS



PLASTER New masonary surfaces must be allowed to cure completely. It is recommended to allow 28 days as the curing time for new masonary surfaces.



CLEANING Surface should be free from any loose paint, dust or grease. Growths of fungus, algae or moss should be removed by wire brushing and water. In case of areas having excessive dampness use Asian Paints SmartCare DampBlock to limit further dampness. When the underlying surface exhibits chalkiness, in spite of thorough surface cleaning, use Asian Paints SmartCare Exterior Sealer.

FILLING FOR CRACKS For filling cracks upto 3mm use Asian Paints SmartCare Crack Seal.



FILLING FOR HOLES & DENTS

In case of dents and holes use Asian Paints Wall Putty or white cement and fine sand in the ratio 1:3

Asian Paints Professional FineTex should not be applied on surfaces / substrates that are subjected to continuous seepage or dampness.

PAINT APPLICATION PROCESS

APPLICATION	PRODUCT CODE	THINNER	DILUTION % (BY VOLUME)	APPLICATION¹ VISCOSITY (SEC)	RECOATING PERIOD ² (HOURS)
STEP 1 ASIAN PAINTS WALL PUTTY (OPTIONAL)	0079	• WATER	BASED ON REQUIREMENT TO FORM PASTE	PASTE FORM	4 HRS
STEP 2 EXTERIOR WALL PRIMER / PROFESSIONAL EXTERIOR PRIMER BRUSH / SPRAY / ROLLER	0065 1019	WATER	BRUSH 90 - 110 SPRAY 40 - 45 ROLLER 90 - 110	BRUSH 15 - 18 SPRAY 33	4 HRS

HORIZONTAL SURFACES LIKE TOP OF WINDOWS. LEDGES SHOULD BE PAINTED WITH 3 COATS OF APEX ULTIMA FOR GREATER PROTECTION

APPLICATION OF PRIMER IS MANDATORY								
STEP 3 FIRST COAT ASIAN PAINTS PROFESSIONAL FINETEX ROLLER	1028	WATER	5-10% IF REQUIRED	N/A	12 - 16 HRS			
STEP 4 2-3 COATS ASIAN PAINTS APEX ULTIMA / APEX / PROPEX BRUSH / SPRAY / ROLLER	0068 0012 1030	WATER	BRUSH MAX 40 SPRAY MAX 40 ROLLER MAX 40	BRUSH 25 - 35 SPRAY 25 - 35	4 - 6 HRS			

- $1. As measured through a Ford cup. \\ 2. Recoat period is quoted for 25 ^{\circ}C and 50 ^{\circ}Relative Humidity, these may vary under different conditions.$
- 3. Some shades may require 3 coats for proper hiding

^{**}Actual coverage may vary from the quoted coverage due to factors such as method and condition of application and surface roughness and porosity.



HOW TO CHOOSE COLOURS

Browse through Asian Paints colour tools to help you find the right colour combination


COLOUR SPECTRA FAN DECK*



ULTIMA BOOK OF COLOUR (FOR HOMES)



IMAGINE EXTERIORS SKYLINE (FOR RESIDENTIAL TOWERS)



APEX DURACAST TEXTURES THAT TRANSFORM



*These shades are for reference only. Please refer to the Colour Spectra or Colour Palette for correct shade reference

FORESITE SERVICE

Choosing the right combination of shades for your home can be difficult. At such times, you could do with some professional help. Asian Paints Foresite provides you with prints for your home in 3 colour combinations, as selected by you. Visit an Asian Paints Colour World retail store which offers this service, and furnish a digital photograph (resolution 300-dpi or more) to the dealer.





Note: Texture/pattern will not show on the image

ADDITIONAL INFORMATION

VOC CONTENT



Asian Paints Apex Duracast Professional Finetex meets the LEEDS VOC criteria as per Indian Green Building Council version 1.0 as tested at Shriram Institute for Industrial Research. Tested for Duracast Professional Finetex White (shade code 0908)

PRECAUTIONS

- > Do not apply when ambient temperature is less than 10°C or if the temperature might drop to this level within 4 hrs of application.
- > Do not over-thin or over-extend the roller.
- Do not use Apcolite Universal Strainers or any other colourants.
- > Stir well before use.
- > Clean the roller and application tools immediately after use.
- Close the container lid firmly after use.
- In coastal areas it is not recommended to leave the intermediate without application of topcoats for a long period of time.

POST PAINTING CARE

For the best performance of the paint, ensure proper washing and cleaning of all algal and fungal growth, if any, at regular intervals of six months

TECHNICAL DETAILS

- a. Drying time: Surface dry time 30 60 min
- b. Sheen levels: NA
- c. Flash point IS101/1987 Part 1, Sec 6: NA
- **d. Stability of thinned paint** To be used within 24 hours

SAFETY FEATURES

- Xindly refer to the MSDS for Asian Paints Apex Duracast Professional Finetex which gives detailed information on safety measures while handling the paint, which is available on request.
- > Store the container with the lid tightly closed in an upright position, in a cool, dry place
- > Keep out of reach of children and away from eatables.
- > May be harmful if swallowed. In case of ingestion seek immediate medical attention.
- > Wear eye protection during application. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- In case of skin contact immediately wash skin with soap and plenty of water. Get medical attention if irritation develops or persists.
- > Do not breathe vapour or spray.It is recommended to wear suitable nose pad during sanding and surface preparation to avoid dust inhalation
- > Do not pour leftover paint down the drain or in water courses.
- In the event of spills, contain spillage using sand or earth. No added Lead, Mercury or Chromium compounds.