

PRODUCT CODE 0016

TruCare Knifing Paste Filler

Asian Paints TruCare Knifing Paste Filler is used on metallic or wooden surfaces for filling of dents and other surface imperfections.



SOLVENT BASED

asianpaints

LEAD FREE* GUARANTEE


* All Asian Paints products contain no added Lead, Mercury, Arsenic or Chromium from April 2008.

PRODUCT BENEFITS

Asian Paints TruCare Knifing Paste Filler has butter like consistency and is easy to apply. It is supplied at ready to use consistency, but can be thinned to desired consistency by using recommended thinner. Upon air drying, it dries hard. Cutting is easy and involves no strain.


PRODUCT FEATURES

AVAILABLE PACKS




Shelf life: 2 years in original tightly closed containers kept away from direct sunlight and excessive heat

FINISH




Refer to sheen levels in technical details

COVERAGE



**Actual coverage may vary from the quoted coverage due to factors such as method and condition of application and surface roughness

DRYING TIME TO RECOAT



AFTER
4-6
HOURS

RECOMMENDED USAGE



Asian Paints TruCare Knifing Paste Filler is recommended for use on metallic or wooden surfaces, after application of recommended primer

HOW TO APPLY

PAINT APPLICATION PROCESS

APPLICATION	CODE	THINNER	DILUTION %	APPLICATION VISCOSITY ¹	RECOATING PERIOD
STEP 1 SANDING	SAND THE SURFACE WITH EMERY PAPER 180 AND WIPE CLEAN				
STEP 2 TRUCARE RED OXIDE METAL PRIMER & TRUCARE WOOD PRIMER BRUSH/SPRAY	0005 0007	MTO*	0 - 5	40 - 45 SEC 40 - 45 SEC	6 - 8 HRS 10 - 12 HRS
STEP 3 TRUCARE KNIFING PASTE FILLER PUTTY KNIFE	0016	MTO*	NOMINAL, IF REQUIRED*	SUPPLY CONSISTENCY	4 - 6 HRS
STEP 4 SANDING	SAND THE SURFACE WITH EMERY PAPER 180 AND WIPE CLEAN				
STEP 5 TRUCARE RED OXIDE METAL PRIMER & TRUCARE WOOD PRIMER BRUSH/SPRAY	0005 0007	MTO*	0 - 5	40 - 45 SEC 40 - 45 SEC	6 - 8 HRS 10 - 12 HRS
STEP 6 SANDING	LIGHT SAND WITH SAND PAPER 320 AND WIPE CLEAN				

1. Recoat times are quoted for 25°C and 50% relative humidity, these may vary under different conditions. *Mineral Turpentine Oil

Ensure that the surface is free from moisture and loose matter. Metal and wooden surfaces should be primed suitably with respective primer and undercoats, prior to the application of TruCare Knifing Paste Filler.

ADDITIONAL INFORMATION

TECHNICAL DETAILS

a. Drying time: surface dry time ~ 30 minutes max

b. Flash point IS101/1987 Part 1, Sec 6: > 30°C [> 85°F]

** Practical spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness.

PRECAUTIONS

- This product is flammable.
- Do not apply when ambient temperature is less than 10°C or if the temperature might drop to this level within 4 hours of application.
- Work in a well-ventilated place. Wear protective clothing like overalls and gloves. Store the product at ambient conditions in well ventilated locations and away from source of ignition and fire. Do not over-thin or over- extend the brush.
- Avoid eye and skin contact. In case of eye and skin contact wash with plenty of clean water.
- Do not inhale or inject. In case of inhalation move to fresh air. Seek medical attention if symptoms persist in both the cases.
- Use protective equipment like rubber/polythene gloves, safety goggles/glasses and face mask while handling the paint.
- In case if settling is noticed, homogenize the material by mixing and use

SAFETY FEATURES

- Kindly refer to the MSDS for TruCare Knifing Paste Filler which gives detailed information on safety measures while handling the paint, available on request.
- Store the container with the lid tightly closed in an upright position, in a cool, dry place.
- Keep out of reach of children and away from eatables.
- May be harmful if swallowed. In case of ingestion, seek immediate medical attention.
- Wear eye protection during application. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- In case of skin contact, immediately wash skin with soap and plenty of water. Get medical attention if irritation develops or persists.
- Do not breathe vapour or spray. It is recommended to wear suitable nose pad during sanding and surface preparation to avoid dust inhalation.
- Do not pour leftover paint down the drain or in water courses.
- In the event of spills, contain spillage using sand or earth.
- No added Lead, Mercury or Chromium compounds.
- Disposal in land filling and not in drain or any water channel